




- All dimensions are measured in inches and [millimeters] from the top of the door to the centerline of the holes.
- Dimensions shown inside boxes  are locator screw mounting holes.

**For 83" HD  
Models SL53, SL54**
**29 fasteners / 32 bearings**
**FRAME LEAF HOLES      DOOR LEAF HOLES**

**For 85" HD  
Models SL53, SL54**
**29 fasteners / 32 bearings**
**FRAME LEAF HOLES      DOOR LEAF HOLES**


# TEMPLATES

## Half Surface Geared Hinges




- All dimensions are measured in inches and [millimeters] from the top of the door to the centerline of the holes.
- Dimensions shown inside boxes are locator screw mounting holes.

### For 95" HD Models SL53, SL54

33 fasteners / 36 bearings

FRAME LEAF HOLES      DOOR LEAF HOLES



### For 120" HD Models SL53, SL54

37 fasteners / 47 bearings

FRAME LEAF HOLES      DOOR LEAF HOLES

