



- All dimensions are measured in inches and [millimeters] from the top of the door to the centerline of the holes.
- Dimensions shown inside boxes are locator screw mounting holes.

**For 83" HD
Models SL53, SL54**
29 fasteners / 32 bearings
FRAME LEAF HOLES DOOR LEAF HOLES

**For 83" HD
Model 77**
32 fasteners / 33 bearings
FRAME LEAF HOLES DOOR LEAF HOLES


TEMPLATES

Half Surface Geared Hinges




- All dimensions are measured in inches and [millimeters] from the top of the door to the centerline of the holes.
- Dimensions shown inside boxes are locator screw mounting holes.

For 85" HD Models SL53, SL54

29 fasteners / 32 bearings


FRAME LEAF HOLES DOOR LEAF HOLES





For 95" HD Models SL53, SL54

33 fasteners / 36 bearings

FRAME LEAF HOLES DOOR LEAF HOLES



- All dimensions are measured in inches and [millimeters] from the top of the door to the centerline of the holes.
- Dimensions shown inside boxes  are locator screw mounting holes.

**For 95" HD
Model 77**
36 fasteners / 36 bearings
FRAME LEAF HOLES DOOR LEAF HOLES

**For 120" HD
Models SL53, SL54**
37 fasteners / 47 bearings
FRAME LEAF HOLES DOOR LEAF HOLES
